

HARO

GERMAN QUALITY FLOORING



Cleaning Instructions for Laminate Floors

Regular Cleaning

Use your BONA mop supplied and the BONA cleaning liquid until this is finished. We then recommend that you refill the cleaning liquid container, with **½ teaspoon of HARO Laminate Flooring Cleaner** (Clean & Green Active). Fill with **COLD water** and reconnect to the spray mop. **Our 'Clean & Green products' are warranted for HARO floors** and should be used to ensure your floor is maintained properly. Clean your floor following the direction of the grain, ensuring you do not over saturate the floor with the liquid. The microfibre pad can be easily removed and washed after use.



Annual Maintenance

Once a year apply **HARO Refresher** (Clean & Green Aqua Shield). This will give your floor a new lease of life, be more durable and better protected against moisture penetrating from above. Simply mop onto your floor and leave to dry for 2 hours before walking on it. It is recommended to clean your floor with **Laminate Flooring Cleaner** (Clean & Green Active) just prior to this protection treatment.



Care Tips for Timber Floors

- DO NOT USE HOT/WARM WATER (COLD WATER ONLY)
- DO NOT USE A WET MOP (JUST DAMP)
- DO NOT USE A STEAM CLEANER – steam is not good for wooden floors; it expands the grain/fibres and allows dirt and moisture to penetrate and stay put.
- AVOID LETTING WATER STAND ON YOUR FLOOR - pets' water bowls or plant pots could hide water underneath
- Do not drag heavy furniture along the floor
- Use felt pads under furniture e.g. bar stools, chairs, tables, and the like.
- Use mats for entry points – small stones caught up under shoe soles could scratch your floor.